

# Contents

## Introductory pages

About this manual	0-5
Introduction to the Honda Shadow (VT600C/CD and VT750C/CD)	0-5
Identification numbers	0-6
Buying parts	0-7
General specifications	0-8
Maintenance techniques, tools and working facilities	0-10
Safety first!	0-16
Motorcycle chemicals and lubricants	0-18
Troubleshooting	0-19

---

## Chapter 1

Tune-up and routine maintenance	1-1	<b>1</b>
---------------------------------	-----	----------

---

## Chapter 2

Engine, clutch and transmission	2-1	<b>2</b>
---------------------------------	-----	----------

---

## Chapter 3

Cooling system	3-1	<b>3</b>
----------------	-----	----------

---

## Chapter 4

Fuel and exhaust systems	4-1	<b>4</b>
--------------------------	-----	----------

---

## Chapter 5

Ignition system	5-1	<b>5</b>
-----------------	-----	----------

---

## Chapter 6

Steering and suspension	6-1	<b>6</b>
-------------------------	-----	----------

---

## Chapter 7

Brakes, wheels, tires and final drive	7-1	<b>7</b>
---------------------------------------	-----	----------

---

## Chapter 8

Bodywork and frame	8-1	<b>8</b>
--------------------	-----	----------

---

## Chapter 9

Electrical system	9-1	<b>9</b>
-------------------	-----	----------

---

## Wiring diagrams

9-24

---

## Conversion factors

9-30

---

## Index

IND-1 **IND**

---



1999 Honda Shadow 600